

Packaged-Products 150 lb (68 kg) or Less



ISTA, Your Alliance in Transport Packaging, is the world leader in Performance Tests for Packaged-Products.

ISTA 1 Series Non-Simulation Integrity Performance Test Procedure

ISTA 1 Series are the most basic category of performance tests.

- They challenge the capability of the package and product to withstand transport hazards, but
- They are not simulations of actual transport hazards, and
- Do not necessarily comply with carrier packaging regulations.

When properly applied, ISTA procedures will provide tangible benefits of:

- Shortened packaged development time and confidence in product launch
- Protection of products and profits with reduced damage and product loss
- Economically balanced distribution costs
- Customer satisfaction and continued business.

There are three sections: Overview, Testing and Report

- Overview provides the general knowledge required before going into the testing laboratory and
- Testing presents the specific instructions to do the testing in the laboratory and
- Report indicates what data shall be recorded to submit a test report to ISTA.

Two systems of weights and measures are presented in ISTA test procedures. They are the English system (Inch-Pound) and the international system SI (Metric). Inch-Pound units are shown first with Metric units in brackets, except in some tables where they are shown separately.

- Either system may be used as the unit of measure (standard units), but
- The standard units chosen shall be used consistently throughout the procedure.
- Units are converted to two significant figures and
- Not exact equivalents.

VERY IMPORTANT:

The entire document shall be read and understood before proceeding with a test.

OVERVIEW OF PROCEDURE 1A

Preface Test Procedure 1A is an integrity test for individual packaged-products.

- It can be used to evaluate the performance of a packaged-product.
- It can be used to compare relative performance of package and product design alternatives.
- The package and product are considered together and not separately.
- Some conditions of transit, such as moisture, pressure or unusual handling, may not be covered.

Other ISTA Procedures may be appropriate for different conditions or to meet different objectives.

Specific suggestions:

- To use random vibration instead of fixed displacement vibration, use ISTA Test Procedure 1G and not 1A.
- For packaged-products where a minimum compression value should be tested, use ISTA Test Procedure 1C.
- For packaged-products intended for international distribution consider ISTA Partial-Simulation Performance Test Procedure 2A.
- For packaged-products that may be transported in a small parcel delivery system consider ISTA General Simulation Performance Test Procedure 3A.
- Refer to Guidelines for Selecting and Using ISTA Procedures and Projects for additional information.

Copyright © 2006 by International Safe Transit Association. All rights Reserved.

1A	OVERVIEW OF PROCEDURE 1A							
Scope	Scope Test Procedure 1A covers testing of individual packaged-products weighing 150 lb (68 kg) or less when prepare shipment.							
	<i>EXCEPTION:</i> Individual packaged-products on a visible skid or pallet and that weigh more than 100 lb (45 kg) may be tested according to Test Procedure 1B or 1E.							
Product Damage Tolerance and Degradation Allowance	 The shipper shall determine the following prior to testing: what constitutes damage to the product and what damage tolerance level is allowable, if any, and the correct methodology to determine product condition at the conclusion of the test and the acceptable package condition at the conclusion of the test. For additional information on this determination process refer to <i>Guidelines for Selecting and Using ISTA Procedures and Projects.</i>							
Samples	identical as possible to actual items. Number of samples required:							
	 One sample is required for the tests in this procedure. Replicate Testing Recommended: To permit an adequate determination of representative performance of the packaged-product, ISTA: Requires the procedure to be performed one time, but Recommends performing the procedure five or more times using new samples with each test. 							
 NOTE: Packages that have already been subjected to the rigors of transportation cannot be assumed to represent state conditions. In order to insure testing in perfect condition, products and packages shipped to certified laborator must be: over-packaged for shipment to the laboratory or repackaged in new packaging at the laboratory. 								
Test Sequence The tests shall be performed on each test sample in the sequence indicated in the following table:					2:			
	Sequence #	Test Category	Test Type	Test Level	For ISTA Certification			
	1	Vibration	Fixed Displacement	1 in (25mm) peak-to- peak at a frequency to be determined	Required			
	2	Shock (Alternative methods	Drop	Height varies with packaged-product weight	Required			

Incline-Impact (Conbur)

Horizontal Impact

(Alternative methods allowed – select one test type)

Impact Velocity varies with packaged-product weight

Impact Velocity varies with packaged-product weight

1A

EQUIPMENT REQUIRED FOR PROCEDURE 1A

Equipment Required Vibration Fixed Displacement Vibration Test:

- Vibration Test System with a 1 in (25 mm) fixed or controlled displacement complying with Method A1 or A2 of the apparatus section of ASTM D 999-01.
 - Rotary or vertical linear motion of the platform is acceptable.
- Metal shim 0.06 in (1.5 mm), thick approximately 2 in (50 mm) wide and at a convenient length.
- Tachometer or suitable indicator for determining vibration frequency in cycles per second (Hz) or cycles per minute (CPM).
- Automatic timer or stopwatch.

Shock

The following alternatives are acceptable for the equipment required for the Shock Test:

Type of Shock Test	Type of Equipment	In compliance with the apparatus section of		
Drop Test	Free fall drop tester	ASTM D 5276-98		
Vertical Shock Test	Shock test machine	ASTM D 5487-98(02)		
Alternative Incline Test	Incline impact tester (conbur)	ASTM D 880-92(02)		
Alternative Horizontal Test	Horizontal impact test system	ASTM D 4003-98		

1A

BEFORE YOU BEGIN PROCEDURE 1A

Identification of Faces, Edges and Corners Prior to beginning the tests identify the faces, edges and corners according to the procedure below.

Step	nning the tests identify the faces, edges and corners according to the procedure below. Action
1	Place the packaged-product in its intended shipping position as determined by shipper. If the shipping position can be variable, place the packaged-product so that the primary shipping label location is on the top face.
2	Does the packaged-product have only six faces (2 sides, 2 ends, top and bottom)?
	• If Yes, then go to Step 5.
	If No, continue to next Step.
3	Develop a method to identify each face, edge and corner and document with a diagram.
4	Go to the next Block.
5	Is the package a corrugated container?
	If Yes, continue to next Step.
	• If No, then go to Step 8.
6	Does the package have a manufacturer's joint connecting a side and an end face?
	If Yes, continue to next Step.
	• If No, then go to Step 8.
7	Turn the packaged-product so that you are looking directly at a face with the manufacturer's joint on the observer's right and go to Step 9.
8	Position one of the smallest width faces of the packaged-product directly in front of you.
	A for the second
10	Identify edges using the numbers of the two faces forming that edge. Example: Edge 1-2 is the edge formed by face 1 and face 2 of the packaged-product.
11	Identify corners using the numbers of the three faces that meet to form that corner. Example: Corner 2-3-5 is the corner formed by face 2, face 3, and face 5 of the packaged-product.
12	Go to next Block.



Packaged-Product Weight and Size Measurement

Before You Begin Vibration Testing

BEFORE YOU BEGIN PROCEDURE 1A

You shall know the packaged-product's:

- gross weight in pounds (kg), and
- outside dimensions of Length, Width and Height (L x W x H) in inches (mm or m)

CAUTION:

A restraining device or devices shall be used with the vibration test system to:

- Prevent the test specimen from moving off the platform and
- Maintain test orientation of the packaged-product, but
- The device or devices shall not restrict the vertical motion of the test specimen during the test.

Familiarity with the following formula is required to calculate the test duration after the frequency required to bounce the packaged-product is determined in the Vibration Test Block:

14, 200 Vibratory Impacts

Test Duration in Minutes =

Cycles Per Minute (CPM) or [Cycles Per Second (Hz) x 60]

The chart below shows example Test Duration's calculated for several frequencies:

СРМ	Hz	Test Duration in Minutes
150	2.5	95
180	3.0	79
210	3.5	68
240	4.0	60
270	4.5	53
300	5.0	48

Before You Begin Shock Testing

The test drop height varies with the weight of the packaged-product. Find the weight of the packaged-product in the following chart to determine a drop height or an equivalent impact velocity or velocity change to be used for a substituted drop:

Packaged-Product Weight			Drop l	Height	Impact '	Velocity	
Equal to or greater than But Less than		ss than	Free Fall		Incline or Horizontal		
lb	kg	lb	kg	in.	mm	ft/s	m/s
0	0	21	10	30	760	13	3.9
21	10	41	19	24	610	11	3.5
41	19	61	28	18	460	10	3.0
61	28	100	45	12	310	8.0	2.5
100	45	150	68	8	200	6.6	2.0

The test method requires the packaged-product to be dropped in several different package orientations.

A drop test must be performed in all required orientations where dropping the packaged-product is practical.

If dropping in a required orientation is not practical an equivalent incline or horizontal test can be substituted for that orientation.

When using impact velocity or velocity change, if any velocity in a Test Sequence is below the required minimum level, that sequence event must be repeated until the test velocity meets the minimum.

1A

TEST SEQUENCE FOR PROCEDURE 1A

The test blocks that follow contain tables that indicate the required steps for each test in the procedure.

Vibration Test Block

	FIXED DISPLA	CEMENT			
Step	Action				
1	Put the packaged-product on the vibration table so that face 3 rests on the platform.				
2	Start the vibration system to vibrate at 1.0 in (25 mm) total displacement at the machine's lowest frequency.				
3	Maintain a fixed displacement at 1 inch (25 mm) and slowly increase the frequency (speed) of the vibration table until the packaged-product begins to momentarily leave the surface of the platform.				
4	Hold the vibration frequency to that determined	in Step 3.			
5	Can a metal shim be intermittently moved between the bottom of the longest dimension of the packaged- product and the surface of the platform?				
	If Yes, hold that frequency and then continue to next Step.				
	• If No, then increase the frequency until the requirement of Step 5 is met, and hold that vibration frequency.				
6	Determine the test duration in minutes using the formula indicated in the Before You Begin Block and the CPM or Hz frequency identified in Step 5.				
7	Begin the vibration duration.				
8	Are you using a vertical linear motion on the vib	ration system?			
	• If No, then continue with the next Step.				
9	Stop the vibration test half way through the vibration indicated in the table below:	ation duration and perform the appropriate action as			
	IF a single 90° horizontal rotation is	THEN perform a horizontal rotation of			
	Possible	90° as the specimen rests on the platform.			
	Not practical because of the size of the packaged-product or the stability of the packaged-product.	180° as the specimen rests on the platform.			
10	Start the vibration system and continue the vibration test at the frequency used in Step 7.				
11	Can a metal shim be intermittently moved between the bottom of the longest dimension of the package product and the surface of the platform?				
	• If Yes, then continue to next Step.				
	• If No, then slowly increase the frequency u	en slowly increase the frequency until the requirement of Step 11 is met.			
12	Complete the vibration duration.				
13	Inspection of the packaged-product for visible damage is allowed, provided inspection does not alter, in any way, the current condition of the package or the condition or position of the product(s).				
14	Vibration testing is now complete. Go to the Shock Test Block.				

1A Shock Test Block

TEST SEQUENCE FOR PROCEDURE 1A

			DROP				
Step	Action						
1	Determine the method(s) of test and the required drop height or impact velocity in the Before You Begin Block.						
2	Do you have a packaged-product with only 6 faces as identified in the Face, Edge and Corner Identification Block?						
	If Yes, continue with the next Step.						
	• If No, then go	 If No, then go to Step 6. 					
3	Test the packaged-product according to the method(s) and level(s) determined in Step 1. Follow the sequence in the table below.						
4	Sequence #	Orientation	Specific face, edge or corner				
	1	Corner	most fragile face-3 corner, if not known, test 2-3-5				
	2	Edge	shortest edge radiating from the corner tested				
	3	Edge	next longest edge radiating from the corner tested				
	4	Edge	longest edge radiating from the corner tested				
	5	Face	one of the smallest faces				
	6	Face	opposite small face				
	7	Face	one of the medium faces				
	8	Face	opposite medium face				
	9	Face	one of the largest faces				
	10	Face	opposite large face				
5	All testing is now complete. Go to the Test Report Block.						
6	Select a bottom face corner to replace the corner required in Step 4 Sequence 1 to begin the test.						
7	Identify the edges of the packaged-product that meet the Step 4 Sequence 2 through 4 requirements.						
8	Select any 6 faces to replace the faces required in Step 4 Sequence 5 through 10.						
9	Using the corner, edges and faces from Steps 6 through 8 go to Step 3 and proceed.						
10	All testing is now complete. Go to the Test Report Block.						



TEST REPORT FOR PROCEDURE 1A

The packaged-product has satisfactorily passed the test if, upon examination, it meets the Product Damage Tolerance and Package Degradation Allowance.

ISTA Certified Testing Laboratories:

- Should file a test report on all ISTA Test Procedures or Projects conducted.
- Shall file a test report on all ISTA Test Procedures or Projects conducted to obtain Transit Tested Package Certification or Acknowledgement.

For additional information, refer to Guidelines for Selecting and Using ISTA Test Procedures and Projects.

ISTA Transit Tested Program

The ISTA Transit Tested Certification Mark as shown is a:

- registered certification mark and
- can only be printed on certified packages and
- can only be used by license agreement and
- by a member of the International Safe Transit Association.



When a member prints this certification mark on a packaged-product, with their license number, they are showing their customer and the carrier that it has passed the requirements of ISTA preshipment testing.

In order to maintain its certified status and eligibility for identification with the TRANSIT TESTED Certification Mark, each packaged-product must be re-tested whenever a change is made in the:

- Product or
- Process or
- · Package.

Changes in the product can include changes in:

- · Design (configuration, components, accessories, etc.) or
- · Size / weight (dimensions, shape, mass, center of gravity, etc.) or
- · Materials (type, construction, fabrication, gage, etc.)

Changes in the process can include changes in:

- · Manufacturing / assembly (vendor, location, automation, etc.) or
- · Filling (equipment, speed, automation, etc.) or
- Distribution system (parcel delivery, LTL, intermodal, etc.)

Changes in the package can include changes in:

- Configuration (individual package or unit load, container type and sub-type, style, design, interior packaging, etc.) or
- Size / weight (dimensions, shape, mass, caliper, gage etc.) or
- · Materials (corrugated, plastic, metal, glass, etc.) or
- · Components (closures, labels, straps, pallets, skids, wraps, etc.)

If corrugated packaging is used, it is recommended that the basis weights of the constituent papers/paperboards be determined after testing and documented to provide the best indicator of equivalence or change.

As a quality control procedure, packaged-products should be re-tested frequently, for example, yearly.

This Test Procedure is published by: International Safe Transit Association 1400 Abbott Road, Suite 160, East Lansing, Mi 48823-1900 USA

Copyright © 2006 by International Safe Transit Association. All rights Reserved

No part of the contents of this Test Procedure may be reproduced or transmitted in any form or by any means without the written permission of the publisher.

Order Information: Additional copies of this Test Procedure, the ISTA RESOURCE BOOK (in print or on CD ROM) may be ordered online at www.ista.org or by contacting ISTA at (+1) 517.333.3437.

ISTA 1A 2001 - Page 8 of 8